



Combi Multi

Combi Oven Cleaning Detergent

Easy to use formulation

Rapidly penetrates greasy deposits

Easy to rinse off

Manual or automatic dispensing

Rubber Friendly

Introduction

Combi Multi is a powerful alkaline detergent for cleaning food residues from the interior of Combi Ovens. It may be used by manual application or through automatic dispensing systems to remove all food residues and other soils from ovens during cleaning cycles.

Directions for use

Manual application: Use Combi Multi undiluted and apply to the interior surfaces of the oven using a hand atomising trigger spray or similar. Allow 5 minutes to react with residues, then activate the oven self cleaning cycle. Where the oven does not have a self cleaning cycle, rub surface with a nylon scouring pad then rinse off with warm fresh water.

For ovens with automatic detergent dispensing systems simply place the detergent feed hose into the drum of Combi Multi and activate self cleaning cycle as normal. Adjust detergent feed to provide 1 part Combi Multi to 50 parts water.

After cleaning is complete wipe the door seals and hinges with Combi Multi diluted 1 part to 9 parts water then rinse off with fresh water

Safety

As this product is hazardous, it is recommended that gloves and safety glasses are worn when handling the concentrate.

Pack Size

15lt

Dilution Rate

1 : 50

